

Vespa

42.L.2 (125 c.c.)

92.L.2 (125 c.c.)

102.L.2 (150 c.c.)

OPERATION AND MAINTENANCE MANUAL



Vespa

42.L.2 (125 c.c.)

92.L.2 (125 c.c.)

102.L.2 (150 c.c.)

OPERATION AND MAINTENANCE MANUAL

INTRODUCTORY NOTE

BE VESPA-WISE

In accordance with the Douglas policy of progressive improvement the right is reserved to alter any details of price, specification, accessories, and equipment, without notice, and without incurring any obligation.

To keep your Vespa in perfect running order, it is advisable to entrust repairs only to authorised Douglas Dealers. We point out that the use of parts other than original "Douglas" Spares will invalidate your Guarantee.

Special care should be taken to ensure that the oil/petrol ratio is always in strict accordance with our recommendations.

DOUGLAS (SALES & SERVICE) LTD., KINGSWOOD, BRISTOL.

Telephone **67-1881**

DIVISION OF THE WESTINGHOUSE BRAKE & SIGNAL Co. Ltd.

Directors: J. W. G. Kershaw (Chairman). C. McCormack (Managing). J. Griffith Hall. N. G. Cadman. H. J. Willis. H. R. Balnes.
E. F. Brockway. B. C. Owen.




FIG. 1




Fig. 2.

VESPA CONTROLS

MAIN SPECIFICATION—125 c.c. MODEL

Frame: Of pressed and spot-welded steel sheet, with stream-lined monocoque type construction.

Suspension: With variable rate coil spring and double action hydraulic damper on both wheels.

Engine: Two-stroke, with reverse flow scavenge. Cast iron cylinder and cast aluminium alloy cylinder head.

| | | | | | | | |
|---------------------|-----|-----|-----|-----|----------|-----|----------------|
| Bore ... | ... | ... | ... | ... | 54 | mm. | (2.126 in.) |
| Stroke ... | ... | ... | ... | ... | 54 | mm. | (2.126 in.) |
| Displacement ... | ... | ... | ... | ... | 123.67 | cc. | (7.48 cu. in.) |
| Max brake power ... | ... | ... | ... | ... | 5 | HP | |
| Compression ratio | ... | ... | ... | ... | 6.5 to 1 | | |

MAIN SPECIFICATION—150 c.c. MODEL

Engine:

| | | | | | | | |
|-------------------|-----|-----|-----|-----|--------------|----------------|----------------|
| Bore ... | ... | ... | ... | ... | 57 | mm. | (2.244 ins.) |
| Stroke ... | ... | ... | ... | ... | 57 | mm. | (2.244 ins.) |
| Displacement ... | ... | ... | ... | ... | 145.6 | c.c. | (8.88 cu. in.) |
| Max. brake power | ... | ... | ... | ... | 5.5 | at 5000 R.P.M. | |
| Compression ratio | ... | ... | ... | ... | 6.1/6.5 to 1 | | |

Transmission: Direct from engine to rear wheel through clutch, cush drive and gear box.

Starting: By means of footstarter, right hand side of scooter.

Gear box: 3-speed drive with constant mesh gears in oil bath. Its adjustable two-cable control is coupled with that of the clutch, on left hand side of handlebars.

Clutch: Wet type, steel plates with cork inserts.

Ignition: By 6-pole flywheel magneto.

Lighting and horn: By flywheel magneto, with a.c. feeding head lamp, tail lamp and horn.

Brakes: Expanding type.

Front brake: control lever on right hand side of handlebars.

Rear brake: control pedal on right hand side of chassis.

Wheels: Of pressed steel sheet, interchangeable and easily removable, following normal car practice.

Tyres: 3.50" \times 8", Michelin.

Fuel Tank: Fitted with three-way Tap Open-Closed—Reserve. The Tap includes a Filter.

| | | | | | | | |
|--------------------------------|-----|-----|-----|-----|-----|----------|----------------------|
| Wheel Base | ... | ... | ... | ... | ... | 1180 mm. | 46.5 in. |
| Max width of Handlebars | ... | ... | ... | ... | ... | 792 mm. | 31.1 in. |
| Max. length of Scooter | ... | ... | ... | ... | ... | 1718 mm. | 67.5 in. |
| Max Height | ... | ... | ... | ... | ... | 1029 mm. | 40.5 in. |
| Height of Saddle | ... | ... | ... | ... | ... | 790 mm. | 31 in. |
| Ground Clearance | ... | ... | ... | ... | ... | 102 mm. | 4 in. |
| Minimum Turning Circle | ... | ... | ... | ... | ... | 1500 mm. | 59 in. |
| Weight—Dry | ... | ... | ... | ... | ... | 86 Kgs. | 190 lbs. (approx) |

Centre stand. A two-leg stand is fitted under the chassis. Two strong return springs hold it in contact with the chassis and keep it from vibrating while the scooter is being ridden.

Tool Kit

2 Double ended Box Spanners, 11—14 mm. and 21—22 mm.

1 Tommy Bar

4 Double Ended Flat Spanners, 8—10 mm. 7—8 mm. 11—14 mm. $\frac{1}{4}'' \times \frac{5}{16}''$ Whit.

1 Screwdriver

Contained in a Roll and housed in nearside wing.

Speedometer. The speedometer is housed in the upper half of the handlebars support, and enhances the appearance of the scooter. It is driven by the front wheel, the flexible shaft being completely enclosed in the steering column.

Routine maintenance can be quite well carried out by any owner, even inexperienced, by carefully following some general rules.

OPERATION

Fuel Supply: Fuel mixture should be composed of Petrol and Grade SAE.30 Oil in the following proportions:—

5% or $\frac{1}{2}$ Pint of Oil to $1\frac{1}{4}$ Gallons of Petrol during and after running in.

Keep the Breather Hole in the Filler Cap clear.

Starting the Engine: Switch on Fuel, put the Gearbox in Neutral and the Throttle in the slow running position, depress the footstarter. If the engine does not readily start make sure that the carburetor is not flooding.

Setting the machine in motion. Let the engine idle, depress the clutch and turn the gear change twistgrip so that the line engraved on it coincides with the figure 1 (1st gear) engraved on handlebars (see Fig. 5). Now let in the clutch gently, whilst opening the throttle gradually to set the machine in motion.

SWITCH POSITIONS.






Fig. 3.
INSTALLATION DIAGRAM.



Gear Change. After reaching the required speed in 1st gear, quickly close the throttle, depress the clutch and turn the gear change twistgrip so that the engraved line is opposite figure 2 (2nd gear), let in the clutch and open the throttle gradually.

Repeat this procedure for changing into 3rd gear.


For changing down, close the throttle, depress the clutch and turn the gear change twistgrip to the required position.

After a little practice, you will find that gears can be changed without using the clutch lever at all, this will not damage the gear box (see the drive system on Fig. 6).


Never let your engine labour when you are forced to reduce speed. Engage the next lower gear without delay.

Do not turn the gear change twistgrip while the engine is not running.


Should gear change troubles arise, particularly if the control becomes stiff, owners should have their machines adjusted by a Service agent or authorised service station.




LOW GEAR.



NEUTRAL.



SECOND GEAR.



TOP GEAR.

Fig. 5.

GEAR CHANGE.




Fig.6.

1. CLUTCH.
2. CUSH GEAR.
3. 3RD GEAR PINION.
4. 2ND GEAR PINION.
5. 1ST GEAR PINION.
6. SELECTOR.
7. GEAR SHAFT.
8. SELECTOR STEM.
9. CLUTCH PINION.

Tyres. The wheels are interchangeable, provided, of course, that they are inflated to the pressures respectively prescribed (see page 15).


When a flat tyre is to be replaced, unscrew the four nuts which secure the wheel to the brake drum, pull the wheel sideways off the studs, repair it or fit the spare wheel (see fig. 7).

Dunlop Tyres, Pressure to be:

| | | | |
|---------|----|---|---------|
| Front | 16 | } | Solo |
| Rear | 20 | | |
| Front | 16 | } | Pillion |
| Rear | 32 | | |
| Front | 16 | } | Sidecar |
| Rear | 24 | | |
| Sidecar | 16 | | |

Pirelli Tyres, Pressures to be:

| | | | |
|---------|----|---|---------|
| Front | 16 | } | Solo |
| Rear | 22 | | |
| Front | 16 | } | Pillion |
| Rear | 32 | | |
| Front | 18 | } | Sidecar |
| Rear | 24 | | |
| Sidecar | 16 | | |



For removing the inner tube, let the air out first, then unscrew the six nuts on the wheel, so that the two halves of the rim fall apart (see fig. 8).




Fig. 8.

HOW TO REMOVE OUTER COVER & INNER TUBE.


These conditions are achieved by adjusting the cables by means of screws indicated with an arrow in Figs. 9 and 10.

Slow running adjustment. No tool is required for this job; idling revs. can be raised by simply tightening the screw which presses on carburettor cover and vice-versa.

Stopping the engine. Push the switch lever to the left. This will leave the cylinder full of fuel vapour, and the next start will be much easier.

Brake adjustment. Brakes are properly adjusted if:—the wheels rotate freely when the control lever and pedal are in rest position, provided the braking action starts as soon as the controls are operated.

Fig. 9.



FRONT BRAKE ADJUSTMENT




Fig. 10.

REAR BRAKE ADJUSTMENT

Important rules to be followed while running in (1,250 miles)

- 1. Do not exceed the following speeds:**

| | |
|-------------|-----------|
| In 1st Gear | 10 m.p.h. |
| In 2nd Gear | 20 m.p.h. |
| In 3rd Gear | 30 m.p.h. |
- 2. Never let your engine labour. If you are forced to reduce speed engage the next lower gear without hesitation.**

MAINTENANCE

Cleaning the scooter. Brushing with paraffin and wiping dry with clean rags is advisable for outside cleaning of engine.

All painted surfaces should be washed with water, cleaned by means of a sponge and wiped dry with chamois leather. Do not use paraffin on such surfaces, since it damages paint and turns it dull.

Before setting the machine in motion, check oil level in gear box by unscrewing on the crankcase the level screw marked "Oil."

When the scooter is upright, oil should just be about to flow out.

After the first 600 miles. Replace oil in the gear box by the procedure as explained in the lubrication chart, page 23. The crankcase can be drained through drain hole.




Fig.11.

Every 1,250 miles. 1. Remove the air cleaner from the carburettor and agitate it in a 30% oil-petrol bath.

2. Check oil level in the gear box (see page 24).

3. Clean the Sparking Electrodes with very fine Emery or suitable files and adjust the Gap to .023/.026" for K.L.G. F.70; .022/.026" for Lodge H.N.; .020" for Champion L.86.

Inspect the insulation material of sparkplug; replace the latter if the porcelain is cracked. Wash with neat petrol.

Use the sparkingplug type prescribed by the Company. We remind owners that the use of an approved sparkingplug will prevent many engine troubles.

4. Clean the two lubricators of front wheel hub and refill them by means of a grease gun. Lubricate the speedometer drive pinion and cable, if necessary.

N.B. All operations indicated hereunder should be carried out by authorised Service Stations.

5. Clean and adjust the contact breaker points of the flywheel magneto (see Fig. 11), to .4 mm. gap (.015 in.).

6. Clean the silencer and decarbonise the engine as explained in Fig. 12 and following notes.




Fig.12.

HEAD, CYLINDER AND PISTONS

Remove the silencer, the cooling hood and the cylinder head (see Fig. 12). Bring the piston to the top dead centre to decarbonise its crown, and clean all carbon deposits from the mouth of the cylinder; then bring the piston to the bottom dead centre and clean the cylinder ports. Decarbonise the inner side of the cylinder head, ensure that the cylinder barrel is free of all carbon.

Heat and clean the exhaust pipe of the silencer, either by scraping it internally with a hooked wire or blowing air through from the opposite end; in both cases the silencer should be held so that the exhaust pipe is turned downwards.

Every 1,800 miles. Grease the felt which lubricates the cam of flywheel magneto. In case of damper troubles, contact your authorised service stations.

Laying up. Clean the Vespa thoroughly. Drop some mineral oil into the engine through the sparkplug hole, and turn the engine over a few times to ensure that a thin oil film spreads all over the internal surfaces to prevent rusting. Support the chassis of the machine on two wooden blocks, ensuring that the tyres are clear of the ground.

N.B. Lubricate exclusively with oil and grease as indicated on lubrication chart, page 23.

LUBRICATION CHART

| Part to be lubricated | | Lubrication | | | | |
|---|--|--|--|---|--|--|
| Every 2,500 | Every 5,000 | *Shell | *B.P. | Esso | Wakefield | Mobil |
| Gear-box topping-up | Gear-box change oil | Shell 2T Two-Stroke Oil or Shell X-100 30 | Engrol Two-Stroke Oil or Engrol SAE. 30 | Esso Extra Motor Oil 20W/30 | Castrol XL | Mobiloil A |
| Front suspension Felt pad on fly-wheel cam Joints on brake control Speedo flexible drive | Control cables Gear change quadrant | Retinax A | Energrease L.2 | Esso Multi-Purpose Grease H | Castrol L.M. | Mobilgrease M.P. |
| Engine at each re-fuelling | | Shell 2T Two-Stroke Oil in ratio of 5% or ½-pint to 1½ galls. petrol | Engrol Two-Stroke Oil in ratio of 5% or ½-pint to 1½ galls. petrol | Essolube 30 in ratio of 5% or ½-pint to 1½ galls. petrol. Esso Two-Stroke Motor Oil in ratio of ½-pint to 1½ galls. petrol | Castrol XL in ratio of 5% or ½-pint to 1½ galls. petrol Castrol Two-Stroke Oil in ratio of ½-pint to 1½ galls. petrol | Mobiloil A in ratio of 5% or ½-pint to 1½ galls. petrol or Mobile Mix in ratio of ½-pint to 1½ galls. petrol |

*Marketed also by National Benzole Co. Ltd., by arrangement with Shell-Mex & B.P. Ltd.

APPROVED PETROL/OIL MIXTURE

| Make | Description |
|---------------------------|-----------------------|
| Shell | 2T Two-Stroke Mixture |
| B.P. | B.P.-Zoom |
| National Benzole Co. Ltd. | Hi-Fli |

Hydraulic Dampers

When not working efficiently consult your Dealer. If servicing is required, they should always be returned to the Works

ENGINE LUBRICATED BY MIXTURE


OIL LEVEL.

GEAR BOX.

FRONT HUB

LUBRICATION SCHEME.

FIG. 13



FAULT FINDING

When the engine does not run properly, make all inspections and rectifications as explained below.

If the suggested remedies do not eliminate the trouble, contact your local dealer.

| Locating the trouble | Remedies | Remarks |
|---|--|---------|
| HARD STARTING 1. Fuel System Fuel tank empty Fuel does not flow to the carburettor although the fuel tap is open or in position "reserve" Filter on Fuel Tap } Filter on carburettor } Clogged, dirty Carburettor body } Main jet and atomizer } Float needle valve sticking on its seating 2. Carburation Engine flooding Tickler sticking in depressed position | Turn to "reserve." Refill as soon as possible (a) Depress the tickler until some fuel drips out, or (b) Unscrew and remove the main jet. If the fuel system is efficient, fuel will come out. (c) Blow through jet orifice to ensure that it is clear Remove and wash in petrol. Blow dry Release by depressing the tickler See page 10 Release | |

| Locating the trouble | Remedies | Remarks |
|--|--|---------------------------------------|
| Float perforated Air cleaner choked or dirty Choke flap sticking in position " closed " Carburettor assembly mounted at an angle 3. Ignition Sparking plug dirty Porcelain of sparking plug cracked Switch lever jammed in " cut out " position Breaker points dirty, partially worn or pitted Gap between breaker points incorrect Breaker points completely worn or pitted Timing wrong Pick-up terminal cracked INCORRECT RUNNING 1. Lack of power Silencer outlet pipe carbonised Induction pipe to cylinder loose Exhaust port partially closed by carbon deposit Cylinder base gasket not tight 2. Poor compression Sparking plug not fully screwed in cylinder head | Replace See page 20 Release Turn to vertical position Disconnect the plug lead. Check if sparking occurs between lead and crankcase when the footstarter is operated Clean—correct Gap according to Maker's recommendations. See page 20 Replace the plug Release the lever Clean with suitable files or very fine emery paper* Correct to .4 mm. with feeler gauge (.015")* Replace* Re-time ignition* Replace Clean Replace the joint washer between pipe and cylinder. Tighten the nuts on cylinder studs Decarbonise cylinder, piston and cylinder head* Replace* Tighten | *To be carried out by a Service agent |

| Locating the trouble | Remedies | Remarks |
|---|---|---------------------------------------|
| 5. Slipping out of gear Gear change control cables out of adjustment Gear shifter loose on crankcase Spring of stirrup broken, feeble or missing Excessive play between actuating arm and gear shift flange Selector arms chamfered Dogs of gear pinions chipped or worn | Adjust* Tighten the screws Replace with new assembly Replace* Replace the selector* Replace the pinions* | |
| 6. Starter assembly not engaging | Contact your Service agent | |
| 7. High fuel consumption I. Fuel level too high in carburettor (a) Tickler sticking in depressed position (b) Float perforated (c) Float needle valve not properly fitting into its seating II. Air cleaner choked or dirty III. Flap of choke valve sticking in closed or partially closed position IV. Retarded ignition V. Poor compression | Release Replace Clean or replace both needle and float chamber cover Clean with pure petrol and blow dry. Dip the metal wadding into a 30% petrol-oil bath Release operating and lubricating the lever on the back of the cleaner case Re-time* See No. 2 of this paragraph | *To be carried out by a Service agent |
| 8. Controls not operating properly Inner cables rusted Excessive play | Lubricate or, if necessary, replace* Adjust* | |

| Locating the trouble | Remedies | Remarks |
|---|---|---------------------------------------|
| 9. Steering becomes stiff | Slacken top race of top ball bearing* Replace bottom race of each bearing* | |
| 10. Excessive play in steering Top race of top bearing loose | Tighten* | *To be carried out by a Service agent |
| 11. Poor braking Stroke of pedal or lever too long Brake linings oily or worn down Brake drums and linings scored | Adjust (See Fig. 9, page 17) Wash with petrol and dry in air, or replace. Ask the Service agent about oil leakage Replace | |
| 12. Inefficiency of suspension Noisy Inefficiency Difficult rotation of wheel spindle | } Contact your Service agent | |
| 13. Engine noisy | | |
| 14. Faulty electric wiring Lead terminals loose or wrongly connected on L.T. socket, pick-up terminal or switch | Contact your Service agent Re-connect properly or replace and tighten the screws. Ask the Service agent, if the trouble is not eliminated by this procedure. | |

N.B. Owners—it is advisable to carry a spare sparking plug, particularly when on a long journey.

Vespa-cult.com

VESPA OWNERS—WHEN REFERRING TO
THIS PUBLICATION, PLEASE QUOTE
THIS CODE:

42.L.2., 92.L.2., 102.L.2./1500/11.61/L.B.545

Vespa-cult.com

